



1. use 6" Peck Prop.
2. all wood is 1/16 sq except as noted
3. cut 1/2 way through longerons just behind cabin and crack to shape body top view...reglue when OK
4. cover with wrinkled paper, no dope or paint
5. fly left left with 1/16 or 3/32 rubber
6. wash out right wing tip if necessary
7. adjust pitch trim with clay ballast

**AKRO**

Dick Baxter  
April 1996